


CH Products FLIGHT SIM Yoke

ELITE button assignments

SAMPLE PROGRAMMABLE* ASSIGNMENTS

Button	Name	Function
1	Trigger	Look Center
3	Rocker Switch 1	Map Screen
4	Rocker Switch 1	Instrument Screen
5	Left Toggle(up)	Flaps Up
6	Left Toggle(down)	Flaps Down
7	Right Toggle(up)	Gear Up
8	Right Toggle(down)	Gear Down
9	Push Button 1	Look Up
10	Push Button 2	Look Down
11	Rocker Switch 2	Trim Down
12	Rocker Switch 2	Trim Up
↑	8-way Hat Switch	View Front
←	8-way Hat Switch	View Left
→	8-way Hat Switch	View Right

USB PORT connection



*

Follow instructions included with the CH FLIGHT SIM Yoke for proper software installation and yoke calibration. See chapter 4 in the *ELITE* Operator's Manual for more information on button assignment & programming.